

**School of Computing**  
**IT8003 Digital Forensics and Investigation**

**Practical 1: Create Case and Process Evidence Mobile**

## Introduction

1. In Digital Forensics once you have acquired the data of the subject's device in a forensically sound manner. The next step before doing your analysis is to do a working copy of the original copy. There after you will want to process the working copy with a forensic software to verify your working copy, extract/crave and begin to perform your analysis.

## Objective

2. In this Practical, you will be able to process the acquire data called image files regarding mobile device and Creating a case file for analysis later on in the practical.

## Before you Begin

3. Please navigate to “C:\Baseimages\ForensicV5”. Look for “**Practical\_1\_Android\_Image**” and extract/copy the file to your preferred location.

## Exercise 1. Creating a Case using Magnet Axiom and Processing Case Evidence

4. Before running “**AXIOM Process**” turn off windows anti-virus first
  - a. **Start > Settings > Update & Security > Windows Security > Virus & threat protection > Manage settings** (or **Virus & threat protection** settings in previous versions of Windows 10)
  - b. Switch **Real-time protection** to **Off**
5. Run “**AXIOM Process**”
6. Click on “**Create New Case**”

The screenshot shows the AXIOM Process interface with a menu bar (File, Tools, Help) and three main sections. The first section, 'CREATE NEW CASE', has a 'CREATE NEW CASE' button highlighted with a red rectangle. The second section, 'ADD EVIDENCE TO EXISTING CASE', includes the text 'Open existing AXIOM case folder' and a 'BROWSE TO A CASE' button. The third section, 'OPEN A RECENT CASE', displays the message 'No recent cases to display'.

7. Fill in the following details in the first Section “CASE DETAILS”
- Case Information
    - Case Name : **DFI\_Mobile\_Practical\_001**
  - Location for Case File
    - Folder Name: **DFI\_Mobile\_Practical\_Case1**
    - File Path: **<Your Preferred Path>**
  - Location For Acquired Evidence (*This location is where you had acquire an evidence and store the image File (.E01, AFF4 etc.) using AXIOM Process*)
    - Folder Name: **DFI\_Mobile\_Practical\_Evidence1**
    - File Path: **<Your Preferred Path>**
  - Scan Information
    - Scanned By: **<Student’s Name>**
    - Description: **Practical Exercise 1: Creating and Processing Evidence Mobile Case**
  - Click on “**Go to Evidence Source**” at the bottom right of the AXIOM Process interface to bring you the next section “**EVIDENCE SOURCES**”.

CASE DETAILS

EVIDENCE SOURCES

PROCESSING DETAILS

ARTIFACT DETAILS

ANALYZE EVIDENCE

CASE DETAILS

CASE INFORMATION

LOCATION FOR CASE FILES

LOCATION FOR ACQUIRED EVIDENCE

SCAN INFORMATION

REPORT OPTIONS

Case number

DFI\_Mobile\_Practical\_001

Case type

Select case type...

Folder name

DFI\_Mobile\_Practical\_Case1

File path

D:\DFI\_Practical

BROWSE

Available space: 781.15 GB

Folder name

DFI\_Mobile\_Practical\_Evidence1

File path

D:\DFI\_Practical\_Evidence

BROWSE

Available space: 781.15 GB

Scanned by

Timothy Tan

Description

Practical Exercise : Creating and Processing Evidence Mobile Case

Cover logo

BROWSE

Image resized to 150x150 pixels

GO TO EVIDENCE SOURCES

## 8. Click on “MOBILE”

CASE DETAILS

EVIDENCE SOURCES

PROCESSING DETAILS

ARTIFACT DETAILS

ANALYZE EVIDENCE

EVIDENCE SOURCES

SELECT EVIDENCE SOURCE

EVIDENCE SOURCES ADDED TO CASE

COMPUTER

MOBILE


CLOUD

Type	Image - location name	Evidence number	Search type	Status
------	-----------------------	-----------------	-------------	--------


BACK

GO TO PROCESSING DETAILS


## 9. Click on “ANDROID”




## 10. Click on “LOAD EVIDENCE”



## 11. Click on “IMAGE”



## 12. Browse to the location where you had saved your extracted “Practical\_1\_Android\_Image.zip” file. Navigate to the file “Android\_Quick Image.zip”.



### 13. Click “Next”

**EVIDENCE SOURCES**

**ADD FILES AND FOLDERS**

CLEAR ALL

- Android\_Quick Image.zip
  - Agent Data
  - Live Data
  - sdcard
    - adb-data.tar

BACK NEXT

### 14. Leave the setting as it is and click “Next”

### 15. Leave the setting as it is and click “Go to Processing Details” at bottom right of the AXIOM Process interface to bring you the next section “PROCESSING DETAILS”.

**EVIDENCE SOURCES**

**SELECT EVIDENCE SOURCE**

COMPUTER MOBILE CLOUD

**EVIDENCE SOURCES ADDED TO CASE**

Type	Image - location name	Evidence number	Search type	Status
Image	Android_Quick Image.zip	Android_Quick Image.zip	Android	Ready

BACK GO TO PROCESSING DETAILS

16. In Digital Forensic principle, data through forensic acquisition, extraction or copied from electronic devices, storage media, and electronic files are authenticated by "hash value". We are required to calculate the hash value of the image that we have acquired from the computer to ensure the integrity of it. Click on **“Calculate Hash Values”**

**PROCESSING DETAILS**

**CASE DETAILS**

**EVIDENCE SOURCES** 1

**PROCESSING DETAILS**

Search archives and mobile backups On

Add keywords to search

Extract text from files (OCR)

Calculate hash values On

Categorize chats

Categorize pictures and videos

Add CPS data to search

Find more artifacts On

**ARTIFACT DETAILS** 368

Computer artifacts

Mobile artifacts 368 of 380

Cloud artifacts

**ANALYZE EVIDENCE**

**ADD KEYWORDS TO SEARCH**

Provide the keywords and regular expressions that you want to include in your search. If a keyword gets a hit during the search, it's added to a Keywords filter in AXIOM Examine.

[ADD KEYWORDS TO SEARCH](#)

**CATEGORIZE CHATS WITH MAGNET.AI**

Enable chat categories so that AXIOM Examine automatically categorizes chat conversations, based on the categories you select, and tags them in the Artifacts explorer.

[CATEGORIZE CHATS WITH MAGNET.AI](#)

**SEARCH ARCHIVES AND MOBILE BACKUPS**

Container files such as archives and mobile backups can be found within other evidence sources. Configure options on this page to search any containers found during your search.

[SEARCH ARCHIVES AND MOBILE BACKUPS](#)

**CALCULATE HASH VALUES**

Import hashes for non-relevant files so they don't appear in your case.

[CALCULATE HASH VALUES](#)

**CATEGORIZE PICTURES AND VIDEOS**

Import hashes for known media files and JSON files from Project VIC and CAID so that AXIOM Examine categorizes them automatically.

[CATEGORIZE PICTURES AND VIDEOS](#)

**ADD CPS DATA TO SEARCH**

If you export data from the Child Protection System (CPS) website to a .csv file, and then import the .csv file into Magnet AXIOM Process, Magnet AXIOM automatically searches the data from the CPS file you exported (such as IP addresses, user names, and more) to find any matches to your case. After processing is complete, Magnet AXIOM Examine tags the matching data in the Artifacts and File system explorers.

[ADD CPS DATA TO SEARCH](#)

[BACK](#) [GO TO ARTIFACT DETAILS](#)

17. Select the **“Calculate hash values for all files so that AXIOM Examine displays these values in the File system Explorer”**

**CALCULATE HASH VALUES**

**CALCULATE HASH VALUES FOR ALL FILES**

Enable AXIOM Process to calculate hash values for each file in an evidence source so that AXIOM Examine displays the hash values for each file in the File system explorer Details section.

Configure hash settings to change the format that hashes are calculated in, to change where imported hash values are stored, and to limit the size of files hashed to decrease processing times.

☒ Calculate hash values for all files so that AXIOM Examine displays these values in the File system explorer.

**CONFIGURE HASH SETTINGS**

**TAG FILES WITH MATCHING HASH VALUES**

Import MD5 and SHA1 hash values for files that are of possible interest to your case so that Examine tags the matching files in the File system explorer.

For example, you can provide hash values for known documents or files so you can quickly determine if these files exist in your evidence. Each MD5 and SHA1 hash value must appear on its own line. AXIOM calculates hash values for all files when this feature is enabled.

**ADD FILE** **ENABLE ALL FILES** Records loaded: 0

Enable	File source	Date loaded	Number of records	Tag

**IGNORE NON-RELEVANT FILES**

Import MD5, SHA1 and NSRL hashes for files that you know are not relevant to your case so that AXIOM doesn't create artifacts for them. For example, you can provide hash values for standard OS icons and screen savers so they don't clutter your evidence. Each MD5, SHA1 and NSRL hash value must appear on its own line.

You can still view ignored files in the File system explorer.


AXIOM calculates hashes for all files when this feature is enabled.

**ADD FILE** **ENABLE ALL FILES** Records loaded: 0


Enable	File source	Date loaded	Number of records

[BACK](#) [GO TO CATEGORIZE CHATS](#)

18. Click on **“Configure Hash Settings”**, a window settings will pop up, scroll down the window settings to **“PROCESSING”** and ensure the check box is tick on **“IMAGE HASH VERIFICATION”** (Gives image file a verification hash)




19. Continue from earlier, scroll down further the window settings to “HASHING” and change the Hashing Format to “MD5, SHA1” (Gives you a MD5 Hash value and SHA1 Hash Value) and then click on “Okay”






20. After all the configurations were selected you may skip all the other configurations and move on to “**ANALYZE EVIDENCE**” on the left column of the interface. (This section displays the source evidence image that you wish to process. In our case is the image file “JustineBeaufort.E01” which we had selected for it earlier)

21. Click on “**Analyze Evidence**” on the bottom right of the AXIOM Process interface to process the evidence.



22. Another window “**AXIOM Examine**” will pop up. This shows that you have successfully started the processing for the evidence image file (.E01).



23. The processing of analyzing and processing the evidence would take up to 30 mins or so to complete due the image file size is relatively small.
24. You can close the **AXIOM Process** Window once processing is done. Proceed to practical 2 of the mobile forensics.

-- End --